



Commercial Maintenance Instructions

Junckers Solid Traditions and Junckers Engineered

Preventative Maintenance

1. Place walk-off mats in doorways to keep out dirt and grit.
2. All tables and chairs must have 1/8" felt floor protector pads on the underside of their legs. Felt pads should be cleaned monthly and replaced every six months.
3. Avoid excess moisture from tracked in water, leaks or over-maintenance such as wet mopping.

As Needed

1. Clean up spills immediately. For sticky spills, quickly wipe up as much as possible, then apply recommended floor cleaner (see back of this page) to a cotton cloth and wipe up any remaining residue.
2. Sweep or vacuum floor to remove all debris. To remove scuffs or stubborn stains that are not removed with recommended floor cleaner, use Original "Goof-off" sparingly, then follow with the cleaner.

Daily Maintenance

1. Sweep or vacuum entire floor with soft bristle broom or soft bristle attachment to remove all dust, grit, and other abrasive particles.
2. After floor has been swept/vacuumed, wipe the entire floor with an untreated dust mop dampened with recommended cleaner. Spray dust mop head with floor cleaner and push across the floor following the direction of the wood grain. Use untreated dust mops only. Replace soiled mop covers as necessary. Continued use of soiled covers will cause streaking and scratching of finish.
3. Vacuum walk-off mats to maximize their dirt and grit trapping ability.

Every Six Months to One Year – Deep Cleaning

Perform as needed to help rejuvenate the look of the floor.

1. After cleaning the floor, use recommended floor cleaner as a spay buff solution by lightly mist the floor, then following with a white pad and buffer (150-175 RPM).
2. Be sure that all residue from the white pad buffing/cleaning procedure is removed from the floor surface by immediately tacking the surface with water-dampened, well wrung-out cloth.

Every Twelve to Eighteen Months – Screen & Recoat

This should be performed as floor begins to show some wear. Do not wait until the finish is worn off and the dirt and spills have had a chance to penetrate to the wood.

1. Make sure the floor is free of grease, wax and oily residue.
2. Abrade the floor using a 3M Maroon All-Purpose pad with 180 grit sanding strips and buffer (150175 RPM).
3. Vacuum floor with soft bristle attachment and tack thoroughly with water-dampened, well wrung-out cotton towels.
4. Apply recommended finish (see back of this page) per label instructions. This will keep floors light, clean, and clear-looking even after several recoats.

Precautions

1. Never “wet mop” the wood floor. Excessive water causes wood to expand and may damage the flooring.
2. Do not use floor cleaner for at least 7 days or until the floor is thoroughly cured after the final coat of finish is applied.
3. Do not place plastic over newly finished floors as it may interfere with the curing process.
4. Do not use any oil soaps or wax products on flooring. Waxing your hardwood floor makes it very difficult to recoat. Do not use dust mop treatments or any maintenance products other than the cleaners recommended below.

Recommended Cleaners

- Junckers Wood Floor Cleaner: 800-878-9663

Recommended Finishes

- BonaKemi Traffic: Junckers Engineered (use on smooth surface flooring only)
(If recoating hand-scraped flooring, please call Junckers at 800-878-9663 for recommended finishes.)



RFS SPORTS • 375 COLUMBIA MEMORIAL PKWY • KEMAH, TX 77565
281.334.6800 • WWW.TEAMRFS.COM • INFO@TEAMRFS.COM